

BUDGET HEIGHT ADJUSTABLE ASSEMBLY INSTRUCTIONS RECTANGULAR DESKS

HeightAdjustableDesks.com

Tel: 08449 670636

Fax: 08449 670642

DRIVE ROD
PROTECTION TROUGH

DRIVE ROD

CRANK HANDLE
CONNECTING ROD

M6 x 15mm
CONNECTING BOLT

MOD PANEL

CRANK HANDLE

HANDLE SPACER

SPLIT PIN

CRANK HANDLE
ANGLE BRACKET

RIGHT HAND
800 END FRAME

HANDLE ANGLE
BRACKET ASSEMBLY

**PRIOR TO ASSEMBLY ENSURE ALL
GEARS ARE GENTLY WOUND DOWN
TO THEIR FULLY CLOSED POSITION**

ASSEMBLY PROCEDURE

- REMOVE PACKAGING FROM ALL COMPONENTS.
- SECURE MOD PANEL TO LEFT HAND END FRAME USING PINS AND CAMBS.
- INSERT DRIVE ROD INTO GEAR OF LEFT HAND LEG.
- TAKE OTHER END OF MOD PANEL AND SECURE TO RIGHT END FRAME WHILST SIMULTANEOUSLY INSERTING DRIVE ROD INTO GEAR.
- FIX CRANK ROD HANDLE BRACKET TO END FRAME.
- INSERT CRANK HANDLE CONNECTING ROD THROUGH ANGLE BRACKET AND PASS THROUGH NYLON SPACER INTO R/H GEAR.
- INSERT SPLIT PIN THROUGH HOLE IN CRANK HANDLE CONNECTING ROD.
- INSERT HANDLE INTO CRANK HANDLE CONNECTING ROD AND WIND FRAME TO MAX HEIGHT.
- POSITION TOP ON FRAME-WORK AND SECURE WITH SUITABLE FIXINGS.
- POSITION DRIVE ROD PROTECTION TROUGH AND SECURE WITH SUITABLE FIXINGS.
- ENSURE ALL CAMBS ARE TIGHT AND SECURE.

